



CURED SILICONE REMOVER

DATA SHEET
06/2019



DESCRIPTION:

Product in paste form to remove old silicone cords and sealants in general.

APPLICATIONS:

The Silicone Remover is indicated to replace cords of sealed of baths, sanitary, sinks, tiles, ceramic, etc. It facilitates the remove of acid, neutral silicone sealants and, to a lesser extent, polyurethane sealants, MS-polymer, and in base water products.

Note: SILICONE REMOVER is aggressive on some determined lacquered materials, paints or plastics. It can produce attack. It's needed to test it in this material. Marble and porous surfaces, these can produce a darkened (is needed to test it the application).

INSTRUCTIONS FOR USE:

The surface must be dry.

1º option: Cut away as much as possible of the sealant material. Clean the surface of water. Perforate the protective membrane of the tube, pressing with the reverse of the cap. Apply the product uniformly throughout the area which requires treatment and let it act during one or two hours. Eliminate the rest of the product and the softened cord with the cutter or knife. Clean the surface with water and soap.

2º option: Apply the product uniformly throughout all the joint and let it act during 24 hours. Eliminate the rest of the product and the softened cord with the cutter or knife. Repeat the process if there is still rest of sealant. Clean the surface with water and soap.

Important: The product loses effectiveness in contact with the water.

PRECAUTIONS: Not to apply on painted or varnishes substrates.

Cleaning of tools and equipment:

Once dry the product must retire the maximum possible with cloth and the rest clean it with water and soap.

TECHNICAL FEATURES:

Colour:	Brown.
Base Material:	Aliphatic hydrocarbons
Point inflammation (DIN 51755):	70º C.
Application temperature:	10-40ºC

STORAGE:

At least 3 years in its unopened original packaging. Keep in cool and dry conditions.

PRESENTATION:

Tubes 85 ml.

CLEANING:

Once dry, the product must be removed as much as possible with a cloth and clean the rest with soap and water.



CURED SILICONE REMOVER

DATA SHEET
06/2019

HEALTH & SAFETY:

Irritates the eyes and the skin. Keep out of the reach of the children. If swallowed, seek medical advice immediately and show product's label. If get in touched with eyes or nostrils, clean with fresh water and call the doctor.

Safety sheet available under requirement.

DO NOT WASH HANDS WITH SOLVENTS.

For more information request Safety Data Sheet.

"The information contained herein is offered in good faith based on Selena's research and is believed to be accurate. However, because conditions and methods of use of our products are beyond our control, this information shall not be used in substitution for customer's tests to ensure that Selena's products are fully satisfactory for your specific applications. Selena's sole warranty is that the product will meet its current sales specifications. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. Selena FM S.A. specifically disclaims any other expressed or implied warranty of fitness for a particular purpose or merchantability. Selena disclaims liability for any incidental or consequential damages. Suggestions of use shall not be taken as inducements to infringe any patent. Technical indications and data appearing in this brochure are based on our current knowledge and experience and we decline all responsibility for consequences derived from inadequate use. Therefore, our guarantee is limited exclusively to the quality of the product supplied. This technical information can be modified without notice. If necessary request it periodically."



Quilosa - Selena Iberia S.L.U.

Centro empresarial Rivas Futura, C/ Marie Curie 19, Planta 6.1, 28521 Rivas, Madrid, Spain,
Tel: +34 902 02 18 02 – Fax: +34 914 999 796, info@quilosa.es, www.quilosa.com